Advanced course of Measurement and Signal Processing 計測信号処理特論

4. Statistical signal processing (Noise Filtering and Correlation function)

- You can comment and ask questions any time in "Chat".
- Please mute your mic to avoid noise and use "rise hand" button and wait when you want to speak.
- Answer a quiz in clicker to register your attendance.
- Your video image will not be recorded.
 Your voice will be recorded.


2021-05-11 Seiichiro Hara harasei@sc.e.titech.ac.jp 1Q, Tuesday 14:20~16:00

Statistical noise removal

- Modeling of signal and noise
 - Yes
 - Weiner filter
 - Adaptive filter
 - movie, picture, music, human voice,...
 - Estimation of original signal considering physical phenomena. → Later
 - No
 - Linear filter
 - Nonlinear filter
 - Averaging

 $\Phi(\omega)$

Wiener inverse filter



Modeling of measured signal

$$Y(\omega) = X(\omega) + N(\omega)$$
, $y_i = x_i + n_i$
 Y, y : measured signal, X, x : signal, N, n : noise

Find φ_i that make $\hat{x}_i = y_i \varphi_i$ using least square method.

$$E\langle (\hat{x}_i - x_i)^2 \rangle = E\langle \sum_i [(x_i + n_i)\varphi_i - x_i]^2 \rangle$$

$$= \sum_i \{E\langle x_i^2 \rangle (1 - \varphi_i)^2 + E\langle n_i^2 \rangle \varphi_i^2 \} - 2\sum_i \varphi_i E\langle n_i x_i \rangle$$

Take partial differential to minimize error


$$\varphi_{i} = \frac{\langle x_{i}^{2} \rangle}{\langle x_{i}^{2} \rangle + \langle n_{i}^{2} \rangle}, \quad \Phi(\omega) = \frac{P_{X}(\omega)}{P_{X}(\omega) + P_{N}(\omega)}$$

$$P_{N}(\omega) \text{ is assuumed constant}$$


No correlation between noise and signal

Moving average(移動平均)

Moving average = Filtering operation



Moving average



Moving average

Weighted moving average

(a)
$$Z_x = \frac{1}{2m+1} \sum_{i=-m}^{m} z_{x+i}$$
 (b, c, d) $Z_x = \sum_{i=-m}^{m} (w_i z_{x+i}) / \sum_{i=-m}^{m} w_i$

Moving average


Noise suppression of simple moving average

$$\sigma_{y}^{2} = \frac{\sigma_{x}^{2}}{N} \qquad \sigma_{y}/\sigma_{x} = \frac{1}{\sqrt{N}}$$

$$\sigma_{x}, \sigma_{y}: \text{ standard deviation of the noise before } /$$

- after the operation
- N: points of averaging
- Supposes noise have no correlation to each other
- The choice of the range of averaging and weight distribution depends on user's experience.
- Waveform may be distorted.

Moving average



Original
$$\sigma_z = 0.31$$
3 points
$$\sigma_z = 0.18$$


$$\approx \sigma_z / \sqrt{3}$$
5 points
$$\sigma_z = 0.14$$

$$\approx \sigma_z / \sqrt{5}$$

Example of moving average

(Hidden slide)

Simple Moving Average (3-SMA's)



Median filter


$$Z_x = \text{median}[z_{x-m}, \dots, z_{x-1}, z_x, z_{x+1}, \dots, z_{x+m}]$$

Definition

$$Z_{x,y} = \text{median} \begin{bmatrix} z_{x-1,y-1}, z_{x,y-1}, z_{x+1,y-1}, \\ z_{x-1,y}, z_{x,y}, z_{x+1,y}, \\ z_{x-1,y+1}, z_{x-1,y+1}, z_{x-1,y+1} \end{bmatrix} \text{ (case of 2D, m=1)}$$


- Works good for independent noise, while keeping fine details.
- Non-linear operation






Cumulative averaging (Ensemble Averagingアンサンブル平均)

Averaging the multiple results





Result of cumulative averaging

Example: Estimation of current distribution in brain

Cumulative averaging

- Averaging the multiple results
- Total of the signal $\sum_{i=1}^{N} s_i = Ns$
- Total of Noise $\sqrt{\sum_{i=1}^{N} n_i} = \sqrt{N} n$
- S/N ratio $\sqrt[Ns]{\sqrt{N}n} = \sqrt{N} \sqrt[S]{n}$
- N times measurement
 - $^{\square} \rightarrow S/N$ ratio improvement \sqrt{N}

Note

• Filtering causes loss of information.

Therefore, try reducing noise in the experimental setup first.

Auto Covariance (自己共分散)

expected value (期待値)

Definition

$$R_{x}(\tau) = E[x(t)x(t+\tau)]$$

$$\approx \frac{\int_0^\ell x(t)x(t+\tau)dt}{\ell}$$


note:

variance (分散)


$$R_{x}(0) = E[x(t)^{2}] = V[x(t)]$$

$$R_x(-\tau) = R_x(\tau)$$
 Even function

$$R_{x}(0) \ge |R_{x}(\tau)| \quad \forall : \tau$$



Examples of Autocovariance



Practical Calculation of Autocovariance


- Calculation
 - Continuous

$$R_{x}(\tau) = \frac{\int_{a}^{b} x(t)x(t+\tau)dx}{b-a}$$

Discrete

$$R_{x\tau} = \frac{\sum_{t=a}^{b} x_t x_{t+\tau}}{b-a+1}$$

computational complexity: $O[N^2]$ O is Landau's symbol



(a) Small $\tau \rightarrow$ Large *b-a* available



(b) Large $\tau \rightarrow$ Limited to small *b-a*

Data length limitation



Auto Correlation Function (ACF)


(自己相関関数)

Normalized Autocovariance

$$r_{x}(\tau) = R_{x}(\tau) / R_{x}(0) = R_{x}(\tau) / [x]$$

Note:

$$r_{x}(0) = 1$$
$$-1 \le r_{x}(\tau) \le 1$$



Correlation length (相関長)





Fig. 3-5 Difference of ACC between two profiles with different wavelength"


Correlation value = 1/e, 0.5, 0.8. Different values are used depending on application field

Classification of Random data



Calculation of ACF

- Data Requirement
 - Long data is required (b- $a >> <math>\tau$)
 - otherwise you must "note" that
 - "Bias" and "Trend" should be removed
 - E[x(t)]=o (mean shoud be zero)
 - Bias → Subtract mean value
 - Trend \rightarrow Linear regression
 - Most signals can be regarded as stationary signal
 (多くの信号が定常ランダム信号と見なせるようになる)



Why the line is a cur

Application of ACF




Fig. Fluctuation of the pressure in a air-duct recorded on roll paper




Fig. Auto correlation of the above fluctuation

Analog instrument calculating ACF




Fig. Analog instrument for ACF

Areal Auto Correlation Function (AACF)

Definition

$$R_z(u,v) = E[z(x,y)z(x+u,y+v)]$$

note:

$$R_z(u,v) = R_z(-u,-v)$$
, $R_z(u,v) \neq R_z(u,-v)$, $R_z(u,v) \neq R_z(-u,v)$ Point symmetry, 点対称 Not line symmetry, 線対称ではない


- Application
 - 3-D surface topography, 2-D Image analysis
 - Find ray direction and period for each direction

対称の例 Example of symmetry


• 点対称Point symmetry




線対称Line symmetry



軸対称Axis Symmetry



• 回転対称Rotational symmetry






















Fig. Machined surface and its areal autocorrelation function

Application of AACF in 3D surface topography parameters

auto-correlation length

Sal

horizontal distance of the ACF(tx, ty) which has the fastest decay to a specified value s, with $0 \le s \le 1$

$$Sal = \min_{tx, ty \in R} \sqrt{tx^2 + ty^2} \quad \text{where } R = \{(tx, ty) : ACF(tx, ty) \le s\}$$

texture aspect ratio

Str

ratio of the horizontal distance of the ACF(tx, ty) which has the fastest decay to a specified value s to the horizontal distance of the ACF(tx, ty) which has the slowest decay to s, with 0 < s < 1


$$Str = \frac{\min}{tx, ty \in R} \sqrt{tx^2 + ty^2}$$


$$tx, ty \in Q \sqrt{tx^2 + ty^2}$$


$$R = \{(tx, ty) : ACF(tx, ty) \le s\}$$

$$Q = \{(tx, ty) : ACF(tx, ty) \ge s \& **\}$$

Str \approx 1: Isotopical (等方性)







Str >> 1: Anisotopical, Directional (非等方性)

ISO 25178-2

Covariance(共分散)

Definition

$$R_{xy}(\tau) = E[x(t) y(t+\tau)]$$

Calculation

$$R_{xy}(\tau) = \frac{\int_{a}^{b} x(t)y(t+\tau)dx}{b-a}$$

$$R_{xy\tau} = \frac{\sum_{t=a}^{b} x_{t} y_{t+\tau}}{b-a+1}$$




Fig. Calculation of Cross Correlation

Cross Correlation Function(相互相関)

Normalization of covariance

$$r_{xy\tau} = \sqrt{\frac{R_{xy\tau}}{R_{x0} R_{y0}}}$$

If 2 signals are same $r_{xy 0} = 1$

otherwise $r_{xy 0} \neq 1$

Application of cross correlation





図-6 ダムからの年間最大日流出土砂量とその日から N 日後の区間平均日河床変動量絶対値の相関係数

Correlation between the soil discharge of the dam and variation of the riverbed



貯水池からの排出土砂の下流への伝播特性 京都大学大学院 〇南修平(㈱ニュージェック) 京都大学防災研究所 藤田正治 (2008) Choose the range to plot carefully. For example, it is too long to set the horizontal axis of the plot to one month to observe a spectrum with a period of about half a day or to observe the peak deviation of the tide level for a few hours.

Report

1. Calculate and display autocorrelation function, amplitude spectrum and power spectrum of hourly tide observational data for 1 month. Explain the phenomenon revealed by the analysis. In addition, explain the cause of the phenomenon.

Notes:

- You may use tidal observational data from Japan Meteorological Agency http://www.data.jma.go.jp/kaiyou/db/tide/genbo/index.php
- · You can choose any location and time (Year, Month). Specify city and time of the data.
- Don't forget to remove trend and bias before calculation.
- 2. Calculate and display cross correlation function of the hourly tide observational data between two locations for 1 month. Explain the phenomenon revealed by the analysis. In addition, explain the cause of the phenomenon.

Notes:

- · Choose a location where the peak tide time is at least 2 hours different.
- It will be interesting if you choose one location within the Seto inland sea and one location outside the Seto inland sea.
- Don't forget to remove trend and bias before calculation.
- In English or Japanese. You can attach Mathematica file, MATLAB file, program code, etc.
- Submission limit: Wednesday, May 26
- Submission to: OCW-i
- If you have questions, refer to the lecturer at least 5 days prior to the submission limit.